

TRÅDLØSE, BATTERIFRIE KONTROLLBOKSER

SW14-080-RFH8
Trådløs soppbryter med boks




PRODUKTBESKRIVELSE

Fra Comepi har vi ulike kontrollbokser med f.eks. soppknapp eller to knapper med piler. Ta kontakt med oss for mer informasjon.

TEKNISKE DATA

IP-klasse	IP66
Materiale hus	Plast
Temperaturområde fra	-25 °C
Temperaturområde til	70 °C



RRH8 (868MHz) and RRH9 (902MHz) receivers Main features			
The wireless signal works at its best when the space is free between the receiver and the transmitter. Eliminate as far as possible obstacles, mostly if they are metallic!			
One operator - White ON pushbutton	Code	Description	Frequency
	SW11-001-RFH8 SW11-001-RFH9 SW11-002-RFH8 SW11-002-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Green START pushbutton	Code	Description	Frequency
	SW11-003-RFH8 SW11-003-RFH9 SW11-002-RFH8 SW11-002-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Black 40mm mushroom pushbutton without latch	Code	Description	Frequency
	SW11-003-RFH8 SW11-003-RFH9 SW11-003-RFH8 SW11-003-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Yellow 40mm mushroom pushbutton without latch	Code	Description	Frequency
	SW11-004-RFH8 SW11-004-RFH9 SW11-004-RFH8 SW11-004-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Black 30mm mushroom pushbutton without latch	Code	Description	Frequency
	SW11-005-RFH8 SW11-005-RFH9 SW11-005-RFH8 SW11-005-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Black 60mm mushroom pushbutton without latch	Code	Description	Frequency
	SW11-006-RFH8 SW11-006-RFH9 SW11-006-RFH8 SW11-006-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Two positions selector switch D-1 maintained	Code	Description	Frequency
	SW11-007-RFH8 SW11-007-RFH9 SW11-007-RFH8 SW11-007-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Two positions selector switchswitch with key D-1 maintained	Code	Description	Frequency
	SW11-008-RFH8 SW11-008-RFH9 SW11-008-RFH8 SW11-008-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Joystick one positions selector switchswitch with return	Code	Description	Frequency
	SW11-009-RFH8 SW11-009-RFH9 SW11-009-RFH8 SW11-009-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Black extended pushbutton	Code	Description	Frequency
	SW11-010-RFH8 SW11-010-RFH9 SW11-010-RFH8 SW11-010-RFH9	Chrome plated zinc die body Plastic body Chrome plated zinc die body Plastic body	868MHz 902MHz 868MHz 902MHz
One operator - Black 90mm wobble palm switch	Code	Description	Frequency
	SW11-000-RFH8 SW11-000-RFH9	Plastic body	868MHz 902MHz

Two operators - UP & DOWN pushbuttons



Code	Description	Frequency
SW21-001-RFH8	Chrome plated zamak body	868MHz
SW24-001-RFH8	Plastic body	868MHz
SW21-001-RFH9	Chrome plated zamak body	902MHz
SW24-001-RFH9	Plastic body	902MHz

Two operators - ON & OFF pushbuttons



Code	Description	Frequency
SW21-002-RFH8	Chrome plated zamak body	868MHz
SW24-002-RFH8	Plastic body	868MHz
SW21-002-RFH9	Chrome plated zamak body	902MHz
SW24-002-RFH9	Plastic body	902MHz

Two operators - START & STOP pushbuttons




Code	Description	Frequency
SW21-003-RFH8	Chrome plated zamak body	868MHz
SW24-003-RFH8	Plastic body	868MHz
SW21-003-RFH9	Chrome plated zamak body	902MHz
SW24-003-RFH9	Plastic body	902MHz

RRH8 (868MHz) and RRH9 (902MHz) receivers Main features



Installation tips

The wireless signal works at its best when the space is free between the receiver and the transmitter.
Eliminate as far as possible obstacles, mostly if they are metallic!



One operator - White ON pushbutton



Code	Description	Frequency
SW1-001-RFH8	Chrome plated zamak body	868MHz
SW1-001-RFH9	Plastic body	902MHz
SW1-001-RFH8	Chrome plated zamak body	902MHz
SW1-001-RFH9	Plastic body	902MHz

One operator - Green START pushbutton



Code	Description	Frequency
SW1-002-RFH8	Chrome plated zamak body	868MHz
SW1-002-RFH9	Plastic body	902MHz
SW1-002-RFH8	Chrome plated zamak body	902MHz
SW1-002-RFH9	Plastic body	902MHz

One operator - Black 40mm mushroom pushbutton without latch



Code	Description	Frequency
SW1-003-RFH8	Chrome plated zamak body	868MHz
SW1-003-RFH9	Plastic body	902MHz
SW1-003-RFH8	Chrome plated zamak body	902MHz
SW1-003-RFH9	Plastic body	902MHz

One operator - Yellow 40mm mushroom pushbutton without latch



Code	Description	Frequency
SW1-004-RFH8	Chrome plated zamak body	868MHz
SW1-004-RFH9	Plastic body	902MHz
SW1-004-RFH8	Chrome plated zamak body	902MHz
SW1-004-RFH9	Plastic body	902MHz

One operator - Black 30mm mushroom pushbutton without latch



Code	Description	Frequency
SW1-005-RFH8	Chrome plated zamak body	868MHz
SW1-005-RFH9	Plastic body	902MHz
SW1-005-RFH8	Chrome plated zamak body	902MHz
SW1-005-RFH9	Plastic body	902MHz

One operator - Black 60mm mushroom pushbutton without latch



Code	Description	Frequency
SW1-006-RFH8	Chrome plated zamak body	868MHz
SW1-006-RFH9	Plastic body	902MHz
SW1-006-RFH8	Chrome plated zamak body	902MHz
SW1-006-RFH9	Plastic body	902MHz

One operator - Two positions selector switch 0-1 maintained



Code	Description	Frequency
SW1-007-RFH8	Chrome plated zamak body	868MHz
SW1-007-RFH9	Plastic body	902MHz
SW1-007-RFH8	Chrome plated zamak body	902MHz
SW1-007-RFH9	Plastic body	902MHz

One operator - Two positions selector switch with key 0-1 maintained



Code	Description	Frequency
SW1-008-RFH8	Chrome plated zamak body	868MHz
SW1-008-RFH9	Plastic body	902MHz
SW1-008-RFH8	Chrome plated zamak body	902MHz
SW1-008-RFH9	Plastic body	902MHz

One operator - Joystick one positions selector switch/switch with return



Code	Description	Frequency
SW1-009-RFH8	Chrome plated zamak body	868MHz
SW1-009-RFH9	Plastic body	902MHz
SW1-009-RFH8	Chrome plated zamak body	902MHz
SW1-009-RFH9	Plastic body	902MHz

One operator - Black extended pushbutton



Code	Description	Frequency
SW1-010-RFH8	Chrome plated zamak body	868MHz
SW1-010-RFH9	Plastic body	902MHz
SW1-010-RFH8	Chrome plated zamak body	902MHz
SW1-010-RFH9	Plastic body	902MHz

One operator - Black 90mm wobble palm switch



Code	Description	Frequency
SW1-001-RFH8	Plastic body	902MHz
SW1-001-RFH9	Plastic body	902MHz