

TRÅDLØSE, BATTERIFRIE KONTROLLBOKSER

SW14-080-RFH8

Trådløs soppbryter med boks



PRODUKTBESKRIVELSE

Fra Comepi har vi ulike kontrollbokser med f.eks. soppknapp eller to knapper med piler. Ta kontakt med oss for mer informasjon.

TEKNISKE DATA

IP-klasse	IP66
Materiale hus	Plast
Temperaturområde fra	-25 °C
Temperaturområde til	70 °C



Installation tips

The wireless signal works at its best when the space is free between the receiver and the transmitter.
Eliminate as far as possible obstacles, mostly if they are metallic!

RRH8 (868MHz) and RRH9 (902MHz) receivers

Main features

Receiver	Frequency	Power	Range
RRH8	868MHz	10W	1000m
RRH9	902MHz	10W	1000m

One operator - White ON pushbutton

Code	Description	Frequency
SW11-001-RFH8	Chrome plated camlock body	868MHz
SW11-001-RFH9	Plastic body	902MHz
SW14-001-RFH8	Chrome plated camlock body	868MHz
SW14-001-RFH9	Plastic body	902MHz

One operator - Green START pushbutton

Code	Description	Frequency
SW11-002-RFH8	Chrome plated camlock body	868MHz
SW11-002-RFH9	Plastic body	902MHz
SW14-002-RFH8	Chrome plated camlock body	868MHz
SW14-002-RFH9	Plastic body	902MHz

One operator - Black 40mm mushroom pushbutton without latch

Code	Description	Frequency
SW11-003-RFH8	Chrome plated camlock body	868MHz
SW11-003-RFH9	Plastic body	902MHz
SW14-003-RFH8	Chrome plated camlock body	868MHz
SW14-003-RFH9	Plastic body	902MHz

One operator - Yellow 40mm mushroom pushbutton without latch

Code	Description	Frequency
SW11-004-RFH8	Chrome plated camlock body	868MHz
SW11-004-RFH9	Plastic body	902MHz
SW14-004-RFH8	Chrome plated camlock body	868MHz
SW14-004-RFH9	Plastic body	902MHz

One operator - Black 30mm mushroom pushbutton without latch

Code	Description	Frequency
SW11-005-RFH8	Chrome plated camlock body	868MHz
SW11-005-RFH9	Plastic body	902MHz
SW14-005-RFH8	Chrome plated camlock body	868MHz
SW14-005-RFH9	Plastic body	902MHz

One operator - Black 60mm mushroom pushbutton without latch

Code	Description	Frequency
SW11-006-RFH8	Chrome plated camlock body	868MHz
SW11-006-RFH9	Plastic body	902MHz
SW14-006-RFH8	Chrome plated camlock body	868MHz
SW14-006-RFH9	Plastic body	902MHz

One operator - Two positions selector switch 0-1 maintained

Code	Description	Frequency
SW11-007-RFH8	Chrome plated camlock body	868MHz
SW11-007-RFH9	Plastic body	902MHz
SW14-007-RFH8	Chrome plated camlock body	868MHz
SW14-007-RFH9	Plastic body	902MHz

One operator - Two positions selector switch with key 0-1 maintained

Code	Description	Frequency
SW11-008-RFH8	Chrome plated camlock body	868MHz
SW11-008-RFH9	Plastic body	902MHz
SW14-008-RFH8	Chrome plated camlock body	868MHz
SW14-008-RFH9	Plastic body	902MHz

One operator - Joystick one positions selector switch with return

Code	Description	Frequency
SW11-009-RFH8	Chrome plated camlock body	868MHz
SW11-009-RFH9	Plastic body	902MHz
SW14-009-RFH8	Chrome plated camlock body	868MHz
SW14-009-RFH9	Plastic body	902MHz

One operator - Black extended pushbutton

Code	Description	Frequency
SW11-010-RFH8	Chrome plated camlock body	868MHz
SW11-010-RFH9	Plastic body	902MHz
SW14-010-RFH8	Chrome plated camlock body	868MHz
SW14-010-RFH9	Plastic body	902MHz

One operator - Black 90mm wobble palm switch

Code	Description	Frequency
SW11-011-RFH8	Chrome plated camlock body	868MHz
SW11-011-RFH9	Plastic body	902MHz

Two operators - UP & DOWN pushbuttons



Code	Description	Frequency
SD21-001-RFH	Chrome plated zamak body	6000Hz
SD24-001-RFH	Plastic body	6000Hz
SD21-001-RFH	Chrome plated zamak body	9070Hz
SD24-001-RFH	Plastic body	9070Hz

Two operators - ON & OFF pushbuttons



Code	Description	Frequency
SD21-002-RFH	Chrome plated zamak body	6000Hz
SD24-002-RFH	Plastic body	6000Hz
SD21-002-RFH	Chrome plated zamak body	9070Hz
SD24-002-RFH	Plastic body	9070Hz

Two operators - START & STOP pushbuttons



Code	Description	Frequency
SD21-003-RFH	Chrome plated zamak body	6000Hz
SD24-003-RFH	Plastic body	6000Hz
SD21-003-RFH	Chrome plated zamak body	9070Hz
SD24-003-RFH	Plastic body	9070Hz